

Chicken Infectious Bursal Disease Antibody (Anti-IBD) ELISA Kit

Catalog No: abx050272

Size: 96T

Range: Qualitative

Sensitivity: Qualitative

Storage: Store at 2-8°C.

Application: The qualitative detection of Anti-IBD in Chicken serum.

Principle of the Assay: This kit is based on competitive enzyme-linked immuno-sorbent assay technology. An antigen is pre-coated onto a 96-well plate. Standards, test samples, and a HRP-conjugated Anti-IBD are added to the wells and incubated. A competitive inhibition reaction takes place between the HRP-labelled Anti-IBD and the unlabelled-Anti-IBD, with the pre-coated antigen. Unbound conjugates are removed using wash buffer. TMB substrate is used to quantify the HRP enzymatic reaction. After TMB substrate is added, only wells that contain sufficient Anti-IBD will produce a blue coloured product, which then changes to yellow after adding the acidic stop solution. The intensity of the color yellow is inversely proportional to the Anti-IBD amount bound on the plate. The OD is measured spectrophotometrically at 450 nm in a microplate reader, from which the concentration of Anti-IBD can be calculated.

Kit Components

- Pre-coated 96-Well Microplate: 12 x 8
- Wash Buffer: (20X) 50 ml
- Positive Control: 1 ml
- Negative Control: 1 ml
- Sample Diluent Buffer: 12 ml
- Detection Reagent: 12 ml
- TMB Substrate A: 6 ml
- TMB Substrate B: 6 ml
- Stop Solution: 6 ml
- Plate Sealer: 3
- Hermetic Bag: 1

Materials Required But Not Provided

- 37°C incubator
- Multi and single channel pipettes and sterile pipette tips
- Squirrt bottle or automated microplate washer
- 1.5 ml tubes
- Distilled water
- Absorbent filter papers
- 100 ml and 1 liter graduated cylinders
- Ice
- Microplate reader (wavelength: 450 nm, or 450/630 nm)
- ELISA Shaker

Protocol

A. Sample Preparation

Analyse immediately or store samples at 2-8°C (within 24 hrs). For long term storage, aliquot and store at -20°C or -80°C. Avoid multiple freeze-thaw cycles. Keep samples on ice during preparation. Equilibrate samples to room temperature prior to analysis.

- **Serum:** Samples should be collected into a serum separator tube. Coagulate the serum by leaving the tube undisturbed in a vertical position overnight at 4°C or at room temperature for up to 1 hr. Centrifuge at approximately 1000 × g for 20 mins. If precipitate appears, centrifuge again. Assay immediately or aliquot and store at -20°C or -80°C.

Notes:

- Store frozen samples undiluted. Once ready to analyse, thaw samples and dilute.
- Fresh samples, or recently obtained samples, are recommended to prevent protein degradation and denaturation that may lead to erroneous results.
- NaN₃ cannot be used as a test sample preservative, since it inhibits HRP.
- If possible, prepare solid samples using sonication and/or homogenization, as lysis buffers may (on occasion) interfere with the kit's performance.
- If a sample is not indicated in the manual applications, a preliminary experiment to determine the suitability of the kit will be required.

B. Reagent Preparation

Wash Buffer: Dilute the concentrated Wash buffer 20-fold (1/20) with distilled water (i.e. add 20 ml of concentrated wash buffer into 380 ml of distilled water). If crystals have formed in the concentrated Wash Buffer, warm to room temperature and mix gently until the crystals have completely dissolved.

C. Assay Protocol

Equilibrate the kit components and samples to room temperature prior to use. It is recommended to measure samples in duplicate.

1. Set 2 positive and 2 negative control, test sample and control (zero) wells on the pre-coated plate respectively, and record their positions. *Add the solution to the bottom of each well without touching the side walls. Pipette the standards and samples up and down to mix before adding to the wells. Avoid foaming or bubbles.*
2. Aliquot 100 µl of negative and 100 µl positive control into the set wells. Aliquot 100 µl of sample diluent buffer in the control (zero) blank well.
3. Aliquot 100 µl of appropriately diluted sample (**1/ dilution**) into the test sample wells. Gently tap the plate to mix, or use a microplate shaker.
4. Cover the plate with a plate sealer and incubate for 30 mins at 37°C.
5. Remove the cover and discard the liquid. Wash the plate 5 times with 1X Wash Buffer. *Fill each well completely with Wash buffer (350 µl) using a multi-channel Pipette or autowasher (1-2 mins soaking period is recommended). Complete removal of liquid at each step is essential for good performance. After the final wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean absorbent paper towels.*
6. Aliquot 100 µl of Detection Reagent to each well (except the blank well). Cover the plate with a plate sealer and incubate for 30 mins at 37°C.
7. Remove the cover, discard the liquid, and repeat the wash process as described above, 5 times.
8. Aliquot 50 µl of TMB Substrate A and 50 µl of TMB Substrate B into each well. Cover the plate with the plate sealer and gently tap the plate to mix thoroughly. Incubate at 37°C for 10-15 mins. The incubation time is for reference only, the optimal time should be determined by end user. Avoid exposure to light.
9. Aliquot 50 µl of Stop Solution into each well. It is important that the Stop Solution is mixed quickly and uniformly throughout the microplate to inactivate the enzyme completely.
10. Ensure that there are no fingerprints or water on the bottom of the plate, and that the fluid in the wells is free of bubbles. Measure the OD at 450 nm immediately.

Instructions for Use

Version: 3.0.0

Revision date: 16 May 2024



This assay is competitive, therefore there is an inverse correlation between the concentration of the sample and the OD measured. Create a graph with the log of the standard concentration (Y) and OD measured (X). Apply a best fit trendline through the standard points. Use this graph to calculate sample concentrations based on their OD values. If the samples have been diluted, the concentration read from the standard curve must be multiplied by the dilution factor.

Data Analysis:

- Mean OD of the Positive Control should be > 0.7 .
- Mean OD of the Negative Control should be ≤ 0.7 .
- CUT OFF value = Negative Control + (if the Mean OD of the Negative Control is < 0.05 , calculate at 0.05; otherwise, calculate at the actual value)

If the Positive Control value is > 0.7 , and the Negative Control value is < 0.7 , the test is valid, otherwise, the test is invalid.

If OD of Samples $<$ CUT OFF, the test samples are considered negative.

If OD of Samples \geq CUT OFF, the test samples are considered positive.

Precautions:

- Before using the kit, centrifuge the tubes to bring down the contents trapped in the lid.
- Do not leave the wells uncovered for extended periods between incubations. The addition of reagents for each step should not exceed 10 mins.
- Ensure that the plate is properly sealed or covered during the incubation steps, and that the time and temperature are controlled.
- Do not reuse pipette tips and tubes.
- Do not use expired components, or components from a different kit.
- The TMB substrate should be used under sterile conditions, and light exposure should be minimised. Unused substrate should be colorless, or a very light yellow in appearance. Do not discard any residual solution back into the vial.
- Please note that this kit is optimised for detection of native samples, rather than recombinant proteins or synthetic chemicals. We are unable to guarantee detection of recombinant proteins, as they may have different sequences or tertiary structures to the native protein.

Technical Support

For troubleshooting, frequently asked questions, and assistance, please visit:

<https://www.abbexa.com/scientific-support/troubleshooting-and-faqs/elisa-kit-scientific-support> or email us at support@abbexa.com.