

Doxycycline (DOX) ELISA Kit

Catalog No: abx365114

Size: 96T

Detection Limit: Serum, Liver, Urine - 20 ng/ml; Egg, Raw Milk, Muscle - 10 ng/ml

Sensitivity: 0.5 ng/ml (ppb)

Cross-reactivity: Chlorotetracycline – 100%; Tetracyclines – 100%; Oxytetracycline – 60%

Storage: Store at 2-8°C.

Application: The qualitative detection of Doxycycline (DOX) in Serum, Liver, Urine, Egg, Raw Milk, and Muscle samples.

Principle of the Assay: This kit is based on competitive enzyme-linked immuno-sorbent assay technology. An antigen is pre-coated onto a 96-well plate. Standards, test samples, and biotin-conjugated reagent are added to the wells and incubated. A competitive inhibition reaction takes place between the the pre-coated DOX and the DOX in the sample with the biotin-labelled antibody. The HRP-conjugated reagent is then added, and the whole plate is incubated. Unbound conjugates are removed using wash buffer at each stage. TMB substrate is used to quantify the HRP enzymatic reaction. After TMB substrate is added, only wells that contain sufficient DOX will produce a blue coloured product, which then changes to yellow after adding the acidic stop solution. The intensity of the color yellow is inversely proportional to the DOX amount bound on the plate. The OD is measured spectrophotometrically at 450 nm in a microplate reader, from which the concentration of DOX can be calculated.

Kit Components

- Pre-coated 96-Well Microplate: 12 x 8
- Wash Buffer: (20X) 25 ml
- Standard (20X): 6 x 1 ml (0 ng/ml, 10 ng/ml, 30 ng/ml, 90 ng/ml, 270 ng/ml, 810 ng/ml)
- Sample Diluent Buffer (20X): 25 ml
- Detection Reagent A: 7 ml
- Detection Reagent B: 12 ml
- TMB Substrate A: 6 ml
- TMB Substrate B: 6 ml
- Stop Solution: 6 ml
- Plate Sealer: 3
- Hermetic Bag: 1

Materials Required But Not Provided

- Incubator
- Multi and single channel pipettes and sterile pipette tips
- Squirt bottle or automated microplate washer
- 1.5 ml tubes
- Distilled water
- Absorbent filter papers
- 100 ml and 1 liter graduated cylinders
- Microplate reader (wavelength: 450 nm)
- ELISA Shaker

Reagents Required But Not Provided

- Trichloroacetic acid
- Acetonitrile

Protocol

A. Reagent Preparation

1 M Trichloroacetic acid Solution: Dilute 16.4 g of Trichloroacetic acid with 100 ml of deionised water.

Standard Working solutions: Dilute each standard vial 20-fold (1/20) with Standard Diluent (i.e. add 1 ml of concentrated standard into 19 ml Standard diluent). **Do not vortex.** Mix with gentle agitation prior to use. Standard Working solutions should be used within 2 hours of preparation.

Sample Diluent Working Solution: Dilute Sample Diluent 20-fold (1/20) with deionized water (i.e. add 25 ml of concentrated sample diluent into 475 ml deionized water). Mix thoroughly.

Wash Buffer: Dilute the concentrated Wash Buffer 20-fold (1/20) with distilled water (i.e. add 25 ml of concentrated wash buffer into 475 ml of distilled water). If crystals have formed in the concentrated Wash Buffer, warm to room temperature and mix gently until the crystals have completely dissolved.

B. Sample Preparation

Sample Collection

Analyse immediately or store samples at 2-8°C (within 24 hrs). For long term storage, aliquot and store at -20°C or -80°C. Avoid multiple freeze-thaw cycles.

- **Serum:** Samples should be collected into a serum separator tube. Coagulate the serum by leaving the tube undisturbed in a vertical position overnight at 4°C or at room temperature for up to 1 hr. Centrifuge at approximately 1000 × g for 20 mins. If precipitate appears, centrifuge again. Assay immediately or aliquot and store at -20°C or -80°C.
- **Muscle, liver and egg samples:** The preparation of tissue homogenates will vary depending upon tissue type – this is just an example. Rinse tissues with ice-cold PBS to remove the excess of blood. Remove any visible fat. Weigh before homogenization. Finely mince tissues and homogenize with a tissue homogenizer on ice in PBS and sonicate the cell suspension. Centrifuge the homogenates at 10000 × g for 5 mins and collect the supernatant.
- **Milk and urine samples:** Centrifuge at approximately 1000 × g for 20 mins to remove precipitate. Analyse immediately or aliquot and store at -20°C or -80°C.

Sample Pretreatment

1. 1 M Trichloroacetic Acid Treatment

- a. **Muscle, raw milk, egg, urine and serum samples:** Add 0.1 ml of 1 M Trichloroacetic acid solution and mix fully.
- b. **Liver samples:** Add 0.2 ml of 1 M Trichloroacetic acid solution and mix fully.

2. Acetonitrile Treatment

- a. **Serum, Liver, Urine, Egg, Raw Milk, and Muscle samples:** Add 1 ml of Acetonitrile, and vortex for 5 minutes. Centrifuge at 4000 rpm for 5 minutes at room temperature. Take 100 µl of the supernatant to a new centrifuge tube, and add 900 µl of Sample Diluent Working Solution. Vortex for 1 minute. Take 50 µl for assay immediately.

Notes:

- Store frozen samples undiluted. Once ready to analyse, thaw samples and dilute .
- Fresh samples, or recently obtained samples, are recommended to prevent protein degradation and denaturation that may lead to erroneous results.
- NaN₃ cannot be used as a test sample preservative, since it inhibits HRP.
- If possible, prepare solid samples using sonication and/or homogenization, as lysis buffers may (on occasion) interfere with the kit's performance.
- If a sample is not indicated in the manuals applications, a preliminary experiment to determine the suitability of the kit will be required.

Instructions for Use

Version: 1.0.7

Revision date: 01 Jun 2023



C. Assay Protocol

Equilibrate the kit components and samples to room temperature prior to use. It is recommended to measure in duplicate.

1. Set sample and standard wells on the pre-coated microplate and record their positions.
Add the solution to the bottom of each well without touching the side walls. Pipette the standards and samples up and down to mix before adding to the wells. Avoid foaming or bubbles.
2. Aliquot 50 µl of appropriately diluted sample into the sample wells.
3. Aliquot 50 µl of each pre-prepared standard into the standard wells. Gently tap the plate to mix, or use a microplate shaker.
4. Aliquot 50 µl of Detection Reagent A into all wells.
5. Cover the plate with a plate sealer and incubate for 30 mins at 25°C.
6. Remove the cover and discard the liquid. Wash the plate 5 times with 1X Wash Buffer. *Fill each well completely with Wash buffer (260 µl) using a multi-channel Pipette or autowasher (1-2 mins soaking period is recommended). Complete removal of liquid at each step is essential for good performance. After the final wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean absorbent paper towels.*
7. Aliquot 100 µl of Detection Reagent B to each well. Cover the plate with a plate sealer and incubate for 30 mins at 25°C in the dark.
8. Remove the cover, discard the liquid, and repeat the wash process as described above, 5 times.
9. Aliquot 50 µl of TMB Substrate A and 50 µl of TMB Substrate B into each well. Cover the plate with the plate sealer and gently tap the plate to mix thoroughly. Incubate at 25°C for 10-15 mins. The incubation time is for reference only, the optimal time should be determined by end user. Avoid exposure to light.
10. Aliquot 50 µl of Stop Solution into each well. It is important that the Stop Solution is mixed quickly and uniformly throughout the microplate to inactivate the enzyme completely.
11. Ensure that there are no fingerprints or water on the bottom of the plate, and that there are no bubbles in the wells. Measure the OD at 450 nm immediately.

Data Analysis:

$$\text{Absorbance (\%)} = \frac{\text{Sample or Standard Absorbance}}{\text{Blank Absorbance}} \times 100$$

The standard curve can be plotted as the relative Absorbance (%) of each reference standard solution (X), against the respective concentration of each standard solution (Y). The concentration of the samples can be interpolated from the standard curve. If the samples measured were diluted, multiply the concentrations from interpolation by the dilution factor, to obtain the concentration before dilution.

Precautions:

- Before using the kit, centrifuge the tubes to bring down the contents trapped in the lid.
- Do not leave the wells uncovered for extended periods between incubations. The addition of reagents for each step should not exceed 10 mins.
- Ensure that the plate is properly sealed or covered during the incubation steps, and that the time and temperature are controlled. Do not reuse pipette tips and tubes.
- Do not use expired components, or components from a different kit.
- The TMB substrate should be used under sterile conditions, and light exposure should be minimised. Unused substrate should be colorless, or a very light yellow in appearance. Do not discard any residual solution back into the vial.
- Please note that this kit is optimised for detection of native samples, rather than recombinant proteins or synthetic chemicals. We are unable to guarantee detection of recombinant proteins, as they may have different sequences or tertiary structures to the native protein.